

Bale Pro[®]

Top Gun[®] BP 663

Operator Manual



www.highlinemfg.com

 **Highline**
MANUFACTURING
A DIVISION OF BOURGALT INDUSTRIES LTD.

E22907_A

Bale Pro[®]

BP 663 TOP GUN[®]

Operator Manual

Starting at Serial No: BP4506901

Highline Manufacturing
HWY #27, P.O. Box 307
Vonda, SK S0K 4N0
Canada
Phone: 306.258.2233
Fax: 306.258.2010
Toll Free: 1.800.665.2010

E22907_A

Highline Team Message

Congratulations on your purchase of the BP 663 TOP GUN® manufactured by Highline Manufacturing.

This Operator Manual has been prepared to provide information necessary for the safe and efficient operation of your BP 663 TOP GUN. In the manual you will find safety procedures, maintenance routines and detailed operational instructions.

If you find that you require information not covered in this manual, please feel free to consult your local dealer. Your dealer is always able to contact Highline for this technical information.

Highline Manufacturing thanks and congratulates you for selecting a BP 663 TOP GUN as your machine of choice.

Highline Manufacturing

Table of Contents

Section 1 - Safety

Serial Number	1	Safety Decals	4
Safety Sign-off Form	2	Safety Decal Locations	11
Safety Alert Symbol	3	Safety Decal Locations	12
General Safety	4		

Section 2 - Transporting the BP 663

Tractor Requirements	2	Place the hitch jack in storage	5
Ensure the correct PTO speed	2	Adjust wheel stance settings	6
Adjust the tractor drawbar length	2	Check the condition of the tires	6
Lift the hitch	3	Raise the bale loading forks	7
Connect the hitch to the tractor	3	Install the cylinder lock	7
Connect the safety chain	3	Ensure the Slow Moving Vehicle (SMV) sign is clean and visible	7
Attach the driveline to the PTO	4	Loaded transport speed	7
Attach the hydraulics	5		
Connect the lights	5		

Section 3 - BP 663 Preparation

Park the tractor and BP 663 on level ground	1	Close the auger drive shield	10
Ensure that all decals are clean	1	Check that the feed rollers are resting on the adjustment plates	10
Ensure that the Slow Moving Vehicle (SMV) sign is clean and visible	1	Adjust the height of the hitch tongue if needed	11
Check the condition of the flail drum and feed rollers	1	BP 663 Models with <u>Standard Forks</u>	11
Check for twine build up on the flail drum and feed rollers	1	Adjust the spacing width of the forks	11
Check the condition of the auger	2	BP 663 Models with <u>Extendable Forks and Twine Sickle</u>	12
Raise the transition housing cover	2	Adjust the spacing of the forks	12
Clear the auger area of any material buildup	3	Adjust the length of the forks	13
Clean debris buildup from flail drum	3	Adjust the Twine Sickle bale guides	14
Check the condition of the flails	4	Adjust the rear deflector shield	15
Remove twine, wrap or other materials wrapped around the flail drum	4	Check that the twine sickle moves	15
Remove any material that has built up at the entrance to the blower housing	4	Check the wear liner in the turret elbow	16
Remove any debris that has collected in the blower housing area	5	Connect the electrical cable	16
Close the lower auger housing cover	5	1 remote (joystick) control is being used on an open center tractor	16
Close the upper auger housing cover	5	Inspect all the hydraulic motors, cylinders and hoses	17
Lower the transition housing access cover	5	Inspect the wheels and tires	17
Check the condition of the blower blades	6	Check that the axle u-bolts are tight	18
Check for cracks along the bend of the blades	6	Remove any twine that is built up around the axle spindle and hub	18
Check the thickness of the blades	7	Ensure the driveline shields are lowered	18
Check the condition of the blower housing wear plate	7	Disengage the flail drum lock	19
Check the condition of the blower drive belt	8	Remove the fork lock from the hydraulic cylinder	19
Check the blower belt tension	9	Lubricate all grease fittings and check fluid level	19
Lower the driveline shield	9	Wrap or Twine Removal Procedure	20
Check the condition of the auger drive belt which is located on the rear tub wall	9		

Section 4 - Operating the BP 663

Unlock the flail drum.....	1	Begin to process a bale.....	13
Discharge Rate Settings	2	Adjust the direction of bale rotation.....	15
Set the aggression level of the flails	2	Re-adjust the discharge rate.....	15
Set the speed of the feed rollers	3	Stop the feed rollers before loading another bale	15
Load the bale into the processor tub.....	3	Operating For Feeding - Not Using the Blower ...	16
Operate the twine sickle	4	Controlling the TOP GUN For Feeding	20
Load a second bale on the forks (optional) ...	5	Control Box - 3 Remote	20
Start the PTO to engage the flail drum	5	1 Remote Joystick Control For Feeding... ..	21
Operating For Bedding - Using the Blower	6	Engage the driveline	22
Controlling the TOP GUN For Bedding .	10	Set the speed of the feed rollers	22
Control Box - 3 Remote	10	Begin to process the bale	22
1 Remote Joystick Control For Bedding.	11	Auger will discharge material	22
Using the Optional Nozzle End Deflector	12	Drive ahead	22
Rotate the nozzle to discharge the material ..	13	Crossing ditches and steep inclines.....	23
Raise or lower the discharge nozzle	13	Making turns	23
Engage the driveline	13	Unplugging the BP 663 TOP GUN	24
Set the speed of the feed rollers.	13		

Section 5 - Maintaining the BP 663

Lubrication.....	1	Blower Belt Tension Adjustment.....	17
Lubricate the turret chain	5	Auger Belt Tension Adjustment.....	18
Visually Inspect Hydraulic Hoses/Fittings	5	Replacing/Installing the Optional Rubber Auger	
Check the Fluid Level in the Flail Gearbox	6	Paddles	18
Flail Gearbox Oil Changing Procedure	6	Adjusting the Hydraulic Motor Gear Into the Turret	
Flail Replacement Procedure	7	Chain	19
Replacing the Blower Blades.....	9	Tires	20
Replacing the Blower Wear Plate	12	Axles	21
Replace the Turret Elbow Wear Liner.....	14		

Section 6 - Storing the BP 663

Clean all the debris	1	Disconnect the safety chain from the tractor.....	2
Park the BP 663 on level ground.....	1	Disconnect the hitch from the tractor	2
Lubricate all BP 663 grease points	1	Relieve the pressure on the hydraulic hoses and	
Tighten all the bolts	1	disconnect them.....	3
Check for worn and damaged parts	1	Disconnect the electrical connection.....	3
Lock the BP 663 flail drum	1	Secure hydraulic hoses and electrical connector ..	3
Lower the forks to the ground	2	Change the oil in the gearbox	3
Place the jack onto the hitch	2	Check the BP 663 for worn and damaged parts ...	3
Remove the driveline from tractor PTO shaft ..	2	Touch-up the paint to prevent rusting	3

Section 7 - Troubleshooting

Blower	2	End Deflector Option, Twine Sickel Option, Hydraulic	
Blower Turret.....	4	Aggression Option	7
Auger.....	5	Joystick Hydraulic Manifold Layout	8
Hydraulic Manifold - Joystick Option	7		

Section 8 - BP 663 Specifications

GENERAL DESCRIPTION OF THE BP 663 TOP GUN® (BP 663)

The BP 663 TOP GUN® is a machine to process round or large square bales of animal feed materials. When the BP 663 TOP GUN is engaged, it uses power from the tractor PTO to rotate a flail drum, a feed auger and a blower. The discharge blower takes power through a belt drive that is clutched to the main driveline. The auger is driven by a belt from the flail drum of the BP 663 TOP GUN. The flails strike the bale and process it into feed size materials or animal bedding sized materials.

The BP 663 TOP GUN moves the processed material through the auger into the blower discharge nozzle. The direction and discharge height of the nozzle is adjustable through hydraulic controls to place the materials at the desired location.

The BP 663 TOP GUN has animal feeding capabilities by placing processed material in a windrow or into a feeding bunk. The blower is disengaged and the auger housing is opened to allow material to be discharged from the side of the machine.

The BP 663 TOP GUN has land reclamation capabilities by placing processed materials into the area requiring the reclamation. The direction and discharge height of the nozzle is adjustable through hydraulic controls to place the materials at the desired location.

The BP 663 TOP GUN come as a model with standard forks or a model with adjustable forks on the rear of the machine. The standard forks model is for picking up and processing round bales only. The adjustable forks model is for picking up and processing both round and square bales. Machines with the adjustable forks come with a twine sickle for cutting the square bale twine. On both models an additional bale may be carried on the forks while the bale in the tub is being processed.

The amount of processing and chopping of material in the processing tub is adjusted by setting the height of the guard rods. The height of the guard rods determine the level of aggression of the flails acting on the bale. The bale is rotated by feed rollers while the flail drum turns to process the material. The rotation of the bale assists in the bale being processed in an even manner.

For animal feeding into a windrow or feed bunk the processed material is discharged from the BP 663 TOP GUN on the right side of the machine.

The operator of the BP 663 TOP GUN is located in the tractor cab to control the speed of driving and the speed of operation of the BP 663 TOP GUN the direction of the blower nozzle output.

INTENDED USE OF THE BP 663 TOP GUN®

The BP 663 TOP GUN is intended to process animal feed and bedding materials from a round or large square bale.

The BP 663 TOP GUN is intended to process and blow land reclamation materials.

The BP 663 TOP GUN is intended for use in farming applications.

The BP 663 TOP GUN is intended for off road use only unless used in land reclamation use. (Get appropriate permits from local authorities for land reclamation applications.)

The BP 663 TOP GUN is intended for use in locations away from people who could be harmed by the discharged materials.

Any uses of the BP 663 TOP GUN other than the above stated Intended Uses shall be considered misuse of the BP 663 TOP GUN. This misuse shall included (but not limited to):

- Using the BP 663 TOP GUN on public roads (except for land reclamation uses).
- Using the BP 663 TOP GUN around people or in public places.
- Discharging materials other than for animal bedding, feed materials or land reclamation.

Always use the BP 663 TOP GUN according to the instructions contained in this Operator Manual and the safety and instruction decals on the machine.

Perform regular maintenance and repair to ensure that the BP 663 TOP GUN operates safely and efficiently.

SERIAL NUMBER

Your serial number is found on the serial number plate (1) attached to the BP 663 TOP GUN® on the top left hand side of the front tub wall.



Serial Plate Location

215068C

It is important to record the serial number for proof of ownership and for any service or maintenance assistance.

Serial Number

Owner

Model

Date of Purchase

Section 1 - Safety

SAFETY SIGN-OFF FORM

Highline Manufacturing follows the general Safety Standards specified by the American Society of Agricultural and Biological Engineers (ASABE) and the Occupational Safety and Health Administration (OSHA). Anyone who will be operating and/or maintaining this machine should read and clearly understand all Safety, Operating and Maintenance information presented in this manual.

Do not operate or allow someone to operate this equipment until this information has been reviewed. This information should be reviewed by all operators before the season start-up.

This sign-off sheet is provided for record keeping to indicate that the person working with the equipment has read and understood the information in this Operator Manual and has been instructed in the safe operation of the equipment.

Date	Employee's Signature	Employer's Signature

SAFETY ALERT SYMBOL

The Safety Alert Symbol means:



**ATTENTION!
BECOME ALERT!
YOUR SAFETY IS INVOLVED!**

The Safety Alert Symbol combined with a Signal Word alert to the presence of a hazard and the degree of possible injury.



Indicates an imminently hazardous situation that, if not avoided, **WILL** result in **DEATH OR SERIOUS INJURY**. The color is Red with White lettering.



Indicates a potentially hazardous situation that, if not avoided, **COULD** result in **DEATH OR SERIOUS INJURY**, and includes hazards that are exposed when guards are removed or unsafe practices. The color is Orange with Black lettering.



Indicates a potentially hazardous situation that, if not avoided, **MAY** result in **MINOR INJURY**. The color is Yellow with Black lettering.

GENERAL SAFETY

1. Ensure that anyone who is going to operate, maintain or work near the BP 663 TOP GUN® is familiar with the recommended operating, maintenance procedures and safety information contained in this manual and follows all the safety precautions.
2. In addition to the design and configuration of the equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence and proper training of personnel involved in the operation, transport, maintenance and storage of the machine.
3. The BP 663 TOP GUN® shall not be operated without all the guards in place.

SAFETY DECALS

1. Keep decals and signs clean and legible at all times.
2. Replace decals and signs that are damaged, missing or have become illegible.
3. Replaced parts that displayed a decal should also display the current decal.
4. Decals are available from the Highline Parts Department.
5. Be familiar with the decals, the type of warning and the area or function(s) related to the area(s) that requires your awareness.




DO NOT CONTACT ROTATING DRIVELINE

Contact with rotating driveline will cause serious injury or death.
Keep all driveline guards in place.
Securely attach drivelines at both ends.
Check that the driveline guards turn freely on the driveline and are attached with the chains.

DO NOT OPERATE WITH SHIELDS MISSING

Stop engine and ensure the PTO driveline is stopped before working on driveline



DO NOT CONTACT ROTATING FLAILS

Contact with moving parts can cause serious injury or death.

Keep hands out of the cutting area and processor tub when the flail drum is rotating.

Always disengage power takeoff, set park brake, lower loader forks to the ground, shut off tractor engine, remove key, and wait for PTO to stop turning before unplugging by hand or servicing.

Stay out of the processor tub when the PTO is connected to the tractor.

Keep guards in place and in good condition.



DO NOT CONTACT THE ROTATING BLOWER

Contact with rotating blower blades can cause serious injury or death.

Keep hands out of the blower chamber when the blower is rotating.

Always disengage power takeoff, set park brake, lower loader forks to the ground, shut off tractor engine, remove key, and wait for PTO to stop turning before unplugging by hand or servicing.

Keep guards in place and in good condition.



DO NOT CONTACT THE ROTATING AUGER

Keep fingers and hand out of the auger chamber.
Never attempt to manually remove debris while the auger is rotating.

Contact with the rotating auger will cause serious injury or death.
Keep all auger guards in place.



DO NOT ENTER TUB WHILE PARTS ARE ROTATING

- With a bale in the tub
- Without a bale in the tub

Before entering the tub

- Turn off the tractor and remove the key.
- Wait for rotating parts to stop

The bale is unstable and may cause entrapment.
Contact with the moving feed mechanism or rotating flail drum will cause serious injury or death.



STAY AWAY FROM OVERHEAD POWER LINES


Stay away from overhead power lines when transporting equipment.

Serious injury or death from electrocution can occur without contacting power lines.



STAY BACK FROM AN OPERATING MACHINE WHICH CAN DISCHARGE OBJECTS SEVERAL FEET

Stay clear when the PTO is engaged.
Stay clear of the nozzle when discharging.
Stay clear from auger side when discharging.



Thrown material or objects leaving the discharge area can cause serious injury or death.

Do not operate within 100 ft (30m) of any person.
Keep all shields and guards in place.



CHECK BLOWER BLADES FOR CRACKS AND THICKNESS

Blower blade pieces that break off will be discharged causing serious injury or death.

Replace all the blades if any blade is cracked along the bend line.

Replace all the blades if any blade is worn to a thickness of 1/8" (3.2 mm) or less.



DO NOT RIDE ON MACHINE

Falling from the moving machine can cause serious injury or death. Falling from the operating machine can cause being entangled under the machine or being injured by the machine.



DO NOT OPERATE WITH SHIELDS MISSING

Contact with the moving belt or sheaves may cause serious injury or death.

Keep shields fastened in place.

Keep away from moving parts.



DO NOT PLACE HAND IN THIS AREA WHEN RAISING OR LOWERING THE LID

Serious injury could result if hands are placed in this clamping area.



INSTALL CYLINDER LOCK BEFORE GOING UNDER RAISED BALE FORKS

Install and secure the cylinder lock before going under raised bale forks.

Install and secure cylinder lock before using the twine cutter.



USE PAPER OR CARDBOARD TO CHECK FOR HYDRAULIC LEAKS

To prevent serious injury or death:

Relieve pressure on hydraulic system before repairing, adjusting or disconnecting.

Wear proper hand and eye protection when searching for leaks.

Use wood or cardboard instead of hands.

Keep all components in good repair.



IMPLEMENT IS DESIGNED FOR OFF ROAD USE ONLY.

Do not transport with bales in the processor tub.

Do not transport with a bale loaded on the forks.


To transport on public roads consult with local traffic authorities.



ENSURE SLOW MOVING VEHICLE SIGN IS IN PLACE

Ensure the Slow Moving Vehicle sign is in place, clean and easily visible.

Ensure the reflectors are in place, clean and easily visible.



AVOID CONTACT WITH THE TWINE SICKLE

Contact with the sharp edges of the twine sickle may result in injury.

Do not contact the twine sickle when it is operating. Contact with the moving sickle may result in injury.



DO NOT EXCEED PTO SPEED

Do not operate at excess speeds or damage to the machine may result.



DO NOT EXCEED 80° TURNS IN OPERATION

Do not operate the Constant Velocity (CV) driveline at greater than 80° to prevent damage to the driveline.




SHUT DOWN TRACTOR BEFORE USING TWINE CUTTER

Use the shutdown procedure to ensure no movement of the flail drum will occur while cutting twine or netwrap.

LOCK FORKS AND FLAIL DRUM BEFORE USING TWINE CUTTER

Lock forks in the upright position before going under the raised forks.

Lock the flail drum to ensure no movement of the flail drum will occur while cutting twine or netwrap.



KEEP THE AXLE U-BOLTS TIGHT


Axles could slide out of the frame if the u-bolts are loose. Tighten u-bolts after first 5 hours of use and then annually.

Do not extend the axles further than 14".



DO NOT ATTEMPT TO LIFT THE HITCH WITHOUT USING THE JACK

READ, UNDERSTAND, AND FOLLOW SAFETY INSTRUCTIONS




Read, understand and follow all instructions and safety messages included in this manual and on decals attached to the machine. These instructions and safety messages contain important information.

Allow only responsible, properly instructed individuals to operate and service the machine.

Failure to follow the instructions and safety messages in this manual and on the decals attached to the machine could result in serious injury or death.

Keep all safety and instruction decals in good condition. Replace any missing or damaged decals

SHUT DOWN THE TRACTOR BEFORE DISMOUNTING TRACTOR



Shut down the tractor and remove the key before repairing, servicing, lubricating or cleaning the machine.


Relieve all hydraulic pressure in the hoses before going near the machine. Leave the hydraulics in the “float” position.

SHUTDOWN PROCEDURE


For your safety and the safety of others, this shutdown procedure must be followed before dismounting from the tractor for inspecting, repairing, servicing, cleaning, or lubricating the machine.

- Step 1: Reduce the engine speed to idle.
- Step 2: Disengage tractor power takeoff.
- Step 3: Set tractor park brake.
- Step 4: Lower bale loader forks to the ground.
- Step 5: Shut off tractor engine and remove key.
- Step 6: Cycle tractor controls to relieve any residual circuit pressure.
- Step 7: Wait for drum and blower to stop turning.

SAFETY DECAL LOCATIONS



SAFETY DECAL LOCATIONS



TRANSPORTING THE BP 663



Only tow a loaded BP 663 on public roads behind a properly sized and equipped tractor that has a weight of 67% or more than the loaded weight of the processor (See below for weight chart.)

Do not tow behind a truck or other type of vehicle.

Check with local traffic regulations to transport on public roads.



Stay away from overhead power lines when transporting equipment. Electrocutation can occur without contacting power lines.




Do not allow any person to ride on the tractor or BP 663. Falling off can result in serious injury or death.



Keep the Axle U-Bolts Tight. Injury could result if axles come out.

Torque the axle u-bolts to 200 lb-ft (270 Nm) to ensure the axles do not slide out of the frame. Maximum axle extension is 14" (355 mm).



1. Tractor Requirements

- Roll Over Protection System (ROPS)
- Working seatbelts
- 1 3/8" 21 spline PTO
- PTO requirement
 - refer to the "Specifications" Section for the PTO requirements.
- 3 Spool Control Valves (SCV)
 - An optional solenoid valve is available for tractors with 2 SCV.
- To transport a BP 663 on public roads at 40 km/h (25 mph) loaded with 2 round bales of 1200 lbs (544 kg) each or 2 square bales of 1800 lbs (816 kg) each, use a properly sized and equipped tractor with a weight at least that shown in the table.

	Tractor Weight at 67% greater than the BP 663 loaded weight
BP 663 - 2 round bales of 1200 lbs (544 kg)	18,178 lbs (8245 kg)
BP 663 - 2 square bales of 1800 lbs (816 kg)	20,182 lbs (9154 kg)

Tractor Weight for Transport at 40 km/h (25 mph)

Note: If bales are heavier adjust the loaded BP 663 weight and the tractor weight accordingly.

2. Ensure the correct PTO speed.

- Ensure that the tractor PTO speed matches the BP 663's gearbox speed of 1000 rpm.
- Do not attempt to operate the BP 663 at a different PTO speed.




Note: Do not use PTO adapters. PTO adapters will cause a driveline failure and possible tractor damage. Your BP 663 warranty will also be invalid.

3. Adjust the tractor drawbar length.

- Set the drawbar length to 16" (406 mm) for a 1 3/8" 21 spline PTO.
- This length is measured from the tip of the PTO shaft end to the center of the drawbar hole. (Refer to your tractor's operator manual for drawbar adjustment procedures.)

Note: To prevent damage to the tractor drawbar, avoid traveling at high speeds and over rough terrain.



Tractor Drawbar Adjustment

PTO Dimensions


4. Lift the hitch with the jack.
 - The hitch is heavy. Do not attempt to lift it without using the jack.
 - Remove the jack from the storage position on the blower housing.
 - Pin the jack onto the hitch.
 - Drop the foot of the jack by rotating the pin and pulling it out.
 - Insert the pin into one of the tube holes.
 - Rotate the pin to lock it.
 - The jack has a 2 speed operating crank (Refer to image on the top of the jack).
 - To quickly lower the jack, pull the handle outward and rotate it counter clockwise.
 - To raise the weight of the hitch at a slower rate, push the handle inward and rotate clockwise.



Lift Hitch with the Jack

221221

5. Connect the hitch to the tractor clevis drawbar.
 - Use a 1" (25 mm) pin.
 - Secure with a hitch pin clip.
6. Connect the safety chain.
 - Route the safety chain around the lower safety chain bolt (1).
 - Attach the chain to a secure location on the tractor.
 - Fasten the chain hook with the hook lock (2).



Connect Hitch to Tractor Drawbar
Connect the Safety Chain

221219-2C

7. Attach the driveline to the PTO.




Shut off the tractor engine before attaching PTO driveline. Entanglement in the rotating driveline can cause serious injury or death.



The BP 663 shall not be operated without the driveline shields in place.

- Shut off the tractor engine and remove the key.
- Check that the driveline telescopes easily and that the shields are in good condition and rotate freely.
- Support the driveline, pull back on the yoke collar, align the splines by rotating the BP 663 driveline and push the driveline into the tractor PTO shaft until the collar snaps into place.
- Push and pull the yoke several times to ensure the driveline is locked. Do not pull on the collar as this will release the lock.
- Lower the tractor & hitch PTO shields into place.
- Connect the chains on the driveline guards to the driveline shield and the tractor.
- Fold down the PTO support holder.
 - Failure to fold down the support may result in damage to the driveline.



Connect the Driveline to the PTO

221220

Section 2 - Transporting the BP 663 TOP GUN®

8. Attach the hydraulics.

- Clean the end of the hoses (1) and the connection.
- Firmly push the hoses into the tractor receptacle according to user preference.
- Route the hoses so they do not interfere with moving parts.



Attach Hydraulics and Electrical
(3 Remote Shown)

108008

9. Connect the lights.

- Connect the light plug into the appropriate tractor receptacle.
- Ensure the light cable does not interfere with or contact moving parts.

10. Raise the jack to release the weight.

- To quickly raise the jack pull the handle outward and turn it clockwise. (Refer to image on the top of the jack.)
- Raise the drop foot and secure it with the pin.

11. Place the hitch jack in the storage location on the blower cover and pin it in place.



Hitch Jack in Storage Location

222182

12. Adjust wheel stance settings.


- Increase the rear wheel stance to maintain stability when working on hilly terrain or rough ground.

Note: Ensure the bale processing tub is empty before adjusting wheel stance.

- Raise the main axle under the cylinder mount and support.
- Loosen the u-bolts (1) that hold the axle tubes in place.
- Slide the axle to achieve the desired wheel stance setting.


Note: Maximum axle extension is 14" (355 mm). Axles may bend if extended beyond this amount.

- Tighten the u-bolts (1) that hold the axle tubes in place to 200 lb-ft (270 Nm).



Wheel Tread Width

221129C



13. Check the condition of the tires.

- Ensure that the lug nuts have the cone side of the lug nut against the wheel rim.
- Torque the lug nuts to 75 lb-ft (101 Nm).
- Fill the tires to 24 psi (165 kPa).




Check the Tires

221128

Section 2 - Transporting the BP 663 TOP GUN®

14. Raise the bale loading forks to the highest position.
15. Install the cylinder lock (1) on the cylinder of the bale loading forks.
 - Fasten the cylinder lock in place with the pin (2).
16. Ensure that the Slow Moving Vehicle (SMV) sign is clean and visible.



Fork Cylinder Resting on Lock
Ensure SMV is Visible

221396

17. Transport on public roads



Do not tow behind a truck or other type of vehicle.

Check with local traffic regulations to transport on public roads.

18. Loaded transport speed on public roads
 - Do not exceed 25 mph (40 km/h).
 - See the chart of required tractor weight at the beginning of this section.

This Page Left Blank

BP 663 PREPARATION

Check these items each time before using the machine.

1. Park the tractor and BP 663 on level ground.
 - Engage the tractor parking brake and shut down the tractor.
2. Ensure that all decals are clean and in place.
3. Ensure that the Slow Moving Vehicle (SMV) sign is clean and visible.
4. Check the condition of the flail drum and feed rollers.



Shut down the tractor completely and set the parking brake.

Disconnect the PTO from the tractor before doing any work near the flail drum.



Do not place hands in the BP 663 when it is rotating. Contact with exposed rotating flails will cause serious injury or death.


5. Check for twine build up on the flail drum and feed rollers.

See "Wrap or Twine Removal Procedure" at the end of this Section.



Park on Level Ground
(Optional Curved Chute and Nozzle End Deflector Shown)

222189



Remove Wrap/Twine from the Feed Rollers

222080

6. Check the condition of the auger.



Disconnect the PTO driveline from the tractor.

Do not place hands in the auger when it is rotating. Contact with the rotating auger will cause serious injury or death.

Do not move the auger housing doors while the flail drum is rotating as this will expose the rotating auger and the rotating blower.



- Raise the upper auger housing cover.
 - Release the handle (1).
 - Raise the cover.
 - Latch the handle in the slot.
- Lower the bottom auger housing cover.
 - Use the lower handle (2) to lower the bottom housing door.




Raise the Auger Housing Cover

212125C

7. Raise the transition housing cover.

- Remove the pin from the bottom of the cover (3).
 - Place the pin back into the tabs.
- Remove the spring pin (4) from the hinge pin (5) at the top of the cover.
- Remove the hinge pin.
- Rotate the cover to the open position.
- Install the hinge pin (5).
- Install the spring pin (4).



Raise the Transition Housing Cover

212129C

8. Clear the auger area of any material buildup.



Do not contact the rotating auger. Never attempt to manually remove debris while the auger is rotating. Contact with the rotating auger will cause serious injury or death.

- Do not use the twine cutter tool to dislodge jammed material.
- Check the condition of the drum.
- Check the condition of the auger flighting.
- Check the condition of the optional rubber paddles (if present).
 - If feeding with the auger it is recommended to install the rubber paddles.

Notes:

- The auger will be imbalanced if some paddles are missing or damaged. This will cause vibration and possible auger bearing damage.
- All the paddles must be replaced as a set if any of them are damaged. The paddles are manufactured to be the same weight to maintain rotational balance.
- Remove twine or other materials wrapped around the auger.

Note: Remove the twine from the auger and blower every 25 bales. Premature bearing failure can occur if twine builds up.

9. Look through the auger and clean debris and material buildup from the flail drum area and the processor tub.



Check Condition of Flighting and Paddles

212124



Remove Twine From Auger

212126



Check and Clean Flail Drum Area
(Auger Not Shown for Clarity)

201204

Section 3 - BP 663 Preparation

10. Look through the auger to check the condition of the flails.
 - Inspect the flails daily.
 - Rotate the flail drum by hand to check all the flails.
 - Check that the flails swing freely.
 - Check if they are broken or worn to the point that they would not process the material properly.
 - See the Section 5 - "Maintaining the BP 663" for flail replacement information.
 - Replace the flails in pairs.
 - Replace on opposite sides of the drum to maintain drum balance.
 - Check the condition of the flail mounting bolts. Ensure the mounting bolts are tight.
11. Remove twine, wrap or other materials wrapped around the flail drum or drum bearings.

Note: Remove the wrap or twine from the flail drum every 25 bales.

- Premature bearing failure can occur if twine is allowed to build up on the flail drum.

See "Wrap or Twine Removal Procedure" at the end of this Section.

12. Remove any material that has built up at the entrance to the blower housing.



Check Flails
(Auger Not Shown for Clarity)

214082



Remove Wrap & Twine
(Auger Not Shown for Clarity)

214083



Remove Material From Blower Entrance

222123

Section 3 - BP 663 Preparation

13. Remove any debris that has collected in the blower housing area.

- Remove any twine that is wrapped around the blower blades.

Note: Remove the twine from the auger and blower every 25 bales. Premature bearing failure can occur if twine is allowed to build up.



Remove Twine & Check Blades


222123

14. Close the lower auger housing cover.

- Move the handle (1) to the closed position.

15. Close the upper auger housing cover.

- Move the handle (2) to the closed position.
- Place the pin firmly into the slot.




Close the Auger Housing Covers

221397C

16. Lower the transition housing access cover.

- Remove the pin from the bottom of the cover (3).
- Remove the spring pin (4) from the hinge pin (5).
- Remove the hinge pin.
- Rotate the cover to the closed position.
- Install the hinge pin (5).
- Install the spring pin (4).
- Install the bottom pin (3).




Lower the Transition Housing Access Cover

212130C

Section 3 - BP 663 Preparation

17. Every week check the condition of the blower blades.


- Open the blower access panel by removing the top nut (1) and the 2 side nuts.
- Lower the panel.



Open the Blower Access Panel

220144C

- Inspect the blower blades through the blower housing access panel.
 - Rotate the blower by hand to inspect all the blades.
- Check for cracks (3) along the bend of the blades.




Inspect the Blower Blades

222114C-2



Blade pieces that break off will be discharged at high speeds causing serious injury or death. Replace all blades as a set.

- Replace all the blades if there is any cracking in a blade.
- Replace all the blades to maintain rotational balance of the blower.



Section 3 - BP 663 Preparation

- Check the thickness of the blades.
 - Replace all the blades if the thickness of any blade is 1/8" (3.2 mm) or less or if there is any cracking (1).
 - Replace all the blades to maintain rotational balance of the blower.

See Section 5 - "Replacing the Blower Blades" for information on changing the blades.


18. Close the blower access panel and fasten with the nuts.
19. Check the condition of the blower housing wear plate.

- The blower housing wear plate is located inside the blower on the discharge side.
- The amount of wear on the plate is dependant on the amount of bales processed and the type of bales.
 - Abrasive bales such as corn bales cause the plate to wear out more quickly.
- The typical high wear area occurs just below the blower housing access panel. (See the diagram.)

The wear plate is reversible. When the wear plate is worn at the location shown (or any other area), reverse the wear plate to avoid wearing out the blower housing structure.


- See Section 5 Maintenance for information on reversing the wear plate

If the wear plate has been reversed and there is wear on both locations of the plate, replace the wear plate.



Check Blades for Cracking and Thickness

222121C




Check Blower Wear Plate
(Impeller Shown Removed for Clarity)

222034C

Section 3 - BP 663 Preparation

- There are 2 ways to check the blower wear plate:


1. Look through the auger transition housing to inspect the blower wear plate.



Check Wear Plate Through Transition Housing ^{212127C}

2. Use a mirror held through the blower housing access panel to view the wear plate.

See Section 5 "Replacing the Blower Wear Plate" for information on replacing the wear plate.



Use a Mirror to Check the Blower Wear Plate ^{222122C}

20. Check the condition of the blower drive belt.

- Lift the drive shield.
 - Rest the shield in the tab on the back of the blower housing.
- Check the blower drive belt.



Lift the Drive Shield
Check Condition of Drive Belt

²²²¹⁴²

21. Check the blower belt tension.
- The spring washer should be showing within the cutout window.
 - See the Section 5 - "Maintaining the TOP GUN" for Blower Belt Tension Adjustment.
 - Lower the blower drive shield and fasten in place.



The TOP GUN shall not be operated without all the driveline shields in place.

22. Lower the driveline shield.



Check Blower Drive Belt and Tension

219061



Lower Drive Shields

222143

23. Check the condition of the auger drive belt which is located on the rear tub wall.
- Open the rear drive shield.
 - Loosen the rubber holder and swing the shield out of the way.
 - The bale forks may need to be raised to fully open the shield.



Open the Rear Drive Shield

221401

Section 3 - BP 663 Preparation

- Check the auger drive belt.
- Check the auger belt tension.
 - The spring washer should be showing within the cutout window.
 - See Section 5 - Belt Tension Adjustment” for Auger Belt Tension Adjustment.

24. Close the auger drive shield into place and fasten with the rubber holder.



The BP 663 shall not be operated without all the driveline shields in place.

25. Check that the feed rollers are resting on the adjustment plates (1).

- The feed roller is to be resting on a side of the adjustment plate (2) that has a line to a cutout.
 - Note: The front and back plate of a roller need to be at the same setting.
- The default positions for the plates are for the left roller (non-discharge side) to be higher than the right roller (discharge side).
 - These default positions are for improved material flow from the machine.
 - Adjustment from these positions is possible.
- Check that all the adjustment plate fasteners (3) are tight.




Check the Auger Belt and Tension

221230



Close the Rear Drive Shield

221396



Check that the Feed Rollers are Resting on the Adjustment Plates

222135C

Section 3 - BP 663 Preparation

26. Adjust the height of the hitch tongue if needed.

Note: Do this procedure on level ground.

- Level the frame of the BP 663 to ensure the bale forks can lower for loading a bale.
- Adjust the hitch tongue height to connect with the tractor drawbar while keeping the frame level.
- Fasten the tongue in place and torque the bolts to 210 ft-lbs (285 Nm).



Adjust the Height of Hitch Tongue

221219-2

27. Adjust the spacing width of the forks.

The BP 663 has 2 models with different types of forks. There is a different method of adjusting the forks for each type.

- Machines with standard forks for use with round bales only.
 - Machines with extendable forks and a twine sickle for use with round bales or square bales.
- BP 663 Models with Standard Forks (For Round Bales Only)
 1. Measure the bale width at about 1/4 of the diameter up from the ground.



Measure Width of Bale for Fork Spacing²²³¹¹⁷



Measure Width of Squatted Bale for Fork Spacing


223118

2. Use the measured width of the bale to adjust the spacing of the forks to be either:

- Between the inner stop tabs (1) for smaller diameter bales.
 - This will give a fork spacing of 35 inches (889 mm).
- Between the outer stop tabs (2) toward the outside of the bale lift for larger diameter bales or squatted bales.
 - This give a fork spacing of 50 inches (1270 mm).


Other factors to consider in setting the width of the forks:

- If bales are sitting too low in the forks, move the forks to the narrower position.
- If the forks are having trouble going underneath the bale, the forks can be moved to the wider position.
- Squatted bales may need wider fork positions. Adjust to suit.



Standard Forks Between Inner Stops

223119C



Standard Forks Between Outer Stops

223121C

- BP 663 Models with Extendable Forks and Twine Sickle (For Round or Square Bales)

1. Adjust the fork spacing:

- For all diameters of round bales, move the forks to the farthest position outward.
- Place the u-bolts around the lift upright.



Forks Moved Out for Round Bales

223122-2

Section 3 - BP 663 Preparation


- For square bales, measure the bale width.



Measure Width Square Bale

223120

- Use the measured bale width to move the forks so the square bale will sit between the inside of the forks (2).
- Loosen the u-bolts (1) that hold the forks to the bale lift.
- Center the forks on the bale lift using the measured width of bale.




Adjust Fork Width to Bales Being Loaded
Center Forks on the Bale Lift

221232C

2. Adjust the length of the forks.

For round bales move both forks inward:

- Remove the spring pin (2) from the fork pin (3).
- Remove the washer.
- Remove the fork pin (3).
- Slide the forks in and align the hole.
- Install the fork pin (3).
- Install the washer.
- Install the spring pin (2) into the fork pin.




Adjust Fork Length for Round Bales

221233C

For square bales move both forks outward:

- Remove the spring pin (2) from the fork pin (3).
- Remove the washer.
- Remove the fork pin (3).
- Slide the forks out and align the hole.
- Install the fork pin (3).
- Install the washer.
- Install the spring pin (2) into the fork pin.



Adjust Fork Length for Square Bales


221234C

3. Adjust the Twine Sickle bale guides.

For Round Bales

Adjust both the left and right bale guide:

- Move the bale guides (1) so they are folded in parallel to the sickle blade.
- Fasten the bale guides with the link pins at the inner connection (2) and the outer connection (3).
- Use the outermost hole at each connection point (2,3).



Bale Guides Folded in for Round Bales
(Left Bale Guide Shown)

222106-1C


For 4 Foot Square Bales

Adjust both the left and right bale guide:

- Move the back pivot of the bale guides (1) into the outer bale guide receivers (4).
- Fasten the bale guide middle support with the link pins to the outer middle guide mount (5).

Note: There are 2 holes in the middle guide mount. These holes allow for additional adjustment of the bale guide.

Pin the guide into the hole that gives the most control on the bale.



Bale Guides Mounted Out for 4 Foot Bales
(Left Bale Guide Shown)

222107-1C


For 3 Foot Square Bales

Adjust both the left and right bale guide:

- Move the back pivot of the bale guides (1) into the inner bale guide receivers (6).
- Fasten the bale guides middle support with the link pins to the inner middle guide mount (7).

Note: There are 2 holes in the middle guide mount. These holes allow for additional adjustment of the bale guide.

Pin the guide into the hole that gives the most control on the bale.



Bale Guides Mounted Out for 3 Foot Bales
(Left Bale Guide Shown) 222108-1C

4. Adjust the rear deflector shield.

- For round bales have the rear deflector pushed in all the way.
- For square bales have the rear deflector pulled out all the way.




Adjust the Rear Deflector Shield
(Deflector Shown Pushed in for Round Bales) 222035

5. Check that the twine sickle moves back and forth by using the tractor control lever.



Avoid contacting the sharp edges of the twine sickle.

Contact with the sharp edges of the sickle may result in injury.




Check the Twine Sickle Moves 222111

Section 3 - BP 663 Preparation

For All Models:

31. Check the wear liner (1) in the turret elbow.

- Remove the nozzle to see into the elbow.
- Retract the elbow cylinder (2) to show the elbow liner (1).
- Replace the wear liner (1) if it is worn. (See information in Section 5 "Maintenance" for replacement procedures.)



Check the Turret Elbow Wear Liner

222110C


32. Connect the electrical cable to a 10 amp fused circuit on the tractor.

- The 1 remote (joystick control) has it's own 15 amp fuse so it is not necessary to connect to a fused circuit.

33. If the 1 remote (joystick) control is being used on an open center tractor, ensure the On/Off solenoid valve that was supplied is installed in the back of the joystick hydraulic block.


To install the solenoid valve:

- Locate the joystick hydraulic block (1) positioned between the inside of the frame members.
- Remove the plug on the port marked "SV" (2).
- Install the solenoid valve (4) into port "SV".
- Locate the cable labeled "X14" (3).
- Connect the cable labeled "X14" (3) to the solenoid valve (4).



Open Center - Remove Plug, Locate Cable

42759SVC



Install the Solenoid Valve and Attach Cable

42759SV-1C

Section 3 - BP 663 Preparation

34. Inspect all the hydraulic motors, cylinders and hoses.



Use a piece of cardboard or heavy paper to check for leaks. Do not use your hand.

Wear proper hand and eye protection when searching for leaks.

Relieve pressure on the hydraulic system before repairing, adjusting or disconnecting.

- Visually inspect all the hydraulic hoses and fittings.
 - See Section 5 "Maintaining the BP 663" for conditions indicating that replacement is needed.
- Ensure the proper size cylinder pins are in place and secured.



Check All Hydraulics

222190

35. Inspect the wheels and tires for damage or foreign objects. Repair or replace as necessary.




Check the Tires

221128

Section 3 - BP 663 Preparation

36. Check that the axle u-bolts (1) are tight.

- Torque the axle u-bolts (1) to 200 lb-ft (270 Nm) to ensure the axles do not slide out of the frame.
- Maximum axle extension is 14" (355 mm) from the main tube edge to the inside face of the spindle plate.



Axle U-bolts Tight
Maximum Axle Extension

221129C

37. Remove any twine that is built up around the axle spindle and hub.

- Be careful to not damage the bearing grease seal while removing twine.



Remove Twine from the Spindle and Hub

221130

38. Ensure the driveline shields are lowered into place and are in good repair to prevent injuries.



The BP 663 shall not be operated without the driveline shields in place.

Note: Connect the chains on the driveline guard to the processor and the tractor.




Lower Driveline Shields

222143

Section 3 - BP 663 Preparation

39. Disengage the flail drum lock.
- Disengage the drum clutch pin (1) from the flail drum drive plate.
 - Pull the spring loaded pin (1) out and rotate to lock in the disengaged position.
 - Failure to unlock the flail drum will result in damage to the machine during start up.



Remove the Flail Drum Lock

221237C

40. Remove the fork lock from the hydraulic cylinder and store on the storage tab.

Note: The forks may need to be raised with the hydraulics to remove the weight from the lock.



Remove Fork Lock

222191

41. Lubricate all grease fittings and check the fluid level in all gear boxes. See the Maintenance Section 5.
42. Ensure all fasteners are tightened.

Wrap or Twine Removal Procedure

Remove wrap or twine that is around the flail drum.

Note: Remove the twine/wrap from the flail drum and feed rollers every 25 bales. Premature bearing failure can occur if twine/wrap is allowed to build up.




Shutdown the tractor completely and set the parking brake.

Disconnect the PTO from the tractor before doing any work near the flail drum.



Do not place hands in the BP 663 when it is rotating. Contact with exposed rotating flails will cause serious injury or death.



1. Raise the forks to fully raised position.



Raise Forks and Lock

221396

2. Install the cylinder locks onto the fork cylinders.



Install and secure the cylinder locks before going under raised bale forks.




Section 3 - BP 663 Preparation

3. Rotate the flail guard rod crank handle (1) to move the pointer (2) to a number between 1 and 4 on the decal.

Note: Having the position at level 5 will result in damage to the twine cutter blade.

4. Align the flail drum knife path with the tub opening on the rear wall.
 - Use the driveline to turn the flail drum to align the knife path.



Set the Aggression of the Flails

222029C

5. Engage the flail drum lock.
 - Turn the lock pin to release the roll pin from the slot.
 - Allow the spring to push the lock pin into the processing chamber.
 - Manually rotate the driveline until the lock pin snaps into place locking the flail drum.
6. Move any flails blocking the knife path.
 - Failure to do so will result in damage to the twine cutter blade.



Engage Flail Drum Lock

221364



Move Flails Blocking the Knife Path

201230

Section 3 - BP 663 Preparation

7. Open the auger drive shield on the rear tub wall.



Open the Rear Drive Shield

221401

8. Remove the twine cutter from the storage position.
 - The twine cutter is located on the non-discharge side of the rear bale tub wall.



Remove Twine Cutter from Storage Position

201231

9. Insert the twine cutter with the blade up.
 - Insert the twine cutter into the guide at the back of the processor tub.
10. Cut through the wrap or twine.
 - Use a “saw” like action along the entire length of the drum.



Insert Twine Cutter with Blade Up

201232

Section 3 - BP 663 Preparation

11. Place the twine cutter back into the storage position.
 - Ensure the handle is facing down and is locked into the key hole slot.



Replace Twine Cutter Into Storage Position

201231

12. Close the auger drive shield and fasten with the latch.



Close the Rear Drive Shield

221396

13. Unlock the flail drum.
 - Disengage the drum clutch pin from the flail drum drive plate.
 - Pull the spring loaded pin (1) out from the processing chamber located at the front of the machine.
 - Rotate to place the lock pin into the slot (2).
 - Failure to unlock the flail drum will result in damage to the machine during start up.



Unlock the Flail Drum

201213

Section 3 - BP 663 Preparation

14. Remove the cut wrap or twine from the flail drum.



Remove Wrap & Twine
(Auger Not Shown for Clarity)

214083

15. Remove the fork lock from the hydraulic cylinder and place in the storage location.



Fork Lock in Storage Location

222191

16. Remove any twine/wrap from around the feed rollers.
- Cut the twine from the rollers.
 - Do not score the paint on the rollers while cutting. Scoring the paint may result in rusting.



Remove Twine/Wrap from the Feed Rollers

222080

OPERATING THE BP 663



Do not allow anyone to ride on the BP 663.

- Falling from the machine can cause injury



Do Not Enter the Tub While Parts Are Rotating

- With Bale in Tub
- Without Bale in Tub

The Bale is unstable and may cause entrapment.

Contact with the moving feed mechanism will cause serious injury or death.

Contact with the rotating flail drum will cause serious injury or death.

Note: Use caution if entering the tub with a bale in it - even after all rotation has stopped. The bale is unstable.



Stay back from an operating machine which can discharge objects several feet.


Thrown material or objects leaving the discharge area can cause serious injury or death.

Do not operate within 100 ft (30m) of any person.

1. Unlock the flail drum.

Pull the spring loaded pin (1) out from the processing chamber located at the front of the machine.

Rotate to place the lock pin into the slot (2).



Unlock the Flail Drum

221363C

Discharge Rate Settings

There are 2 settings that determine the discharge rate of material:

- The aggression level of the flails acting on the bale.
- The speed of the feed rollers which feed the bale into the flail drum.

1. Set the aggression level of the flails by adjusting the guard rods.

The bale rests on the guard rods. The amount of contact between the bale and the flails is determined by the guard rod setting.

Adjust the aggression level of the flails by cranking the guard rod adjustment handle (1).

To Increase the discharge rate:

- Turn the crank handle (1) to move the pointer (2) to a higher number on the decal.

To Decrease the discharge rate:

- Turn the crank handle (1) to move the pointer (2) to a lower number on the decal.

If the Optional Hydraulic Aggression Control is installed:


- Activate the hydraulic cylinder to change the position of the guard rods.
- Use the aggression level rod and the decal for a reference point.
- On the joystick use the "Accessory" function to adjust the aggression.

To Increase the discharge rate:

- Raise the pointer to a higher number.

To Decrease the discharge rate:

- Lower the pointer to a lower number.



Set the Aggression of the Flails

222029C



Optional Hydraulic Aggression Control

221406

2. Set the speed of the feed rollers.

Adjust the feed roller speed to a maximum of 40 rpm.

- Adjust using the tractor flow control settings.
- Faster feed roller speeds will result in a faster discharge of material.
- Slower feed roller speeds will result in a slower discharge of material.

3. Load the bale into the processor tub.

- The dump fork indicator rod (1) gives a visual indication if the forks are raised or are lowered to the ground.
- Lower the forks completely.



Ensure people are not near the machine when lowering the forks and backing up to bales.

- Slowly back up to the bale until the forks are completely under the bale.

For Square Bales:

- Load square bales "on string" (twine on the ground). This will enable the sickle to cut the twine.
 - If it is desired to keep one or two strings on the bale, remove sickle knives from the bar for those string locations.
- Have the bale guides set for the type and size of bale. (See Section 3 for more information.)
- Have the rear deflector pulled all the way out.
- Raise the forks to lift the bale off the ground.



Set Feed Roller Speed

221228



Dump Fork Indicator Rod
(Standard Forks Shown)

221144C



Back Up to the Bale

221245

4. Operate the twine sickle with the tractor remote to cut the twine for square bales.
 - If the joystick is present, use the "Accessory" function to operate the twine sickle.

Note: Have the sickle bale guides set for the size of bale being processed.
Adjust the bale guides if the bale moves too much.
See Section 3 for more information.




Twine Sickle for Square Bales

222111



Avoid Contact with the Twine Sickle

Do not contact the twine sickle when it is operating. Contact with the moving sickle may result in injury.



Note: The twine sickle does not retain the cut twine and does not keep the twine out of the processing tub.

Note: If livestock is being fed, it is the operator's responsibility to ensure that the materials in the processed feed mix are suitable. Some of the wrapping material (twine, net wrap or other materials) may be discharged with the feed if the wrapping materials are not removed prior to processing.

- If a bale is frozen to the ground, dislodge it by rocking the machine to impact the bale and loosen it.
- Ensure flail drum and feed rollers are not turning while loading a bale.
- Raise the lift forks until the bale falls into the processor.



Raise Bale into Processor Tub

221246

Section 4 - Operating the BP 663

5. Load a second bale on the forks (optional) while a bale is in the processor tub.

Note: Load square bales "on string" (twine on the ground). This will enable the sickle to cut the twine.

If a second bale is loaded onto the forks, raise the forks as high as possible.

- Make sure the bale on the forks does not interfere with the bale already in the tub.
- Raising the forks will reduce the pressure on the hydraulic lift assembly.



Second Bale Loaded on Forks
(Square Bale Shown)

221247

Extendable & Standard Forks

6. Start the PTO to engage the flail drum.



Stay clear from discharge side when PTO is engaged.

Do not operate within 100 ft (30m) of any person.

Discharged material or objects leaving the discharge area can cause serious injury or death.



The BP 663 shall not be operated without the guards in place or in good condition.

- Engage the tractor PTO at an idle.
- Increase the tractor RPM until 1000 PTO speed is reached.



Operating For Bedding - Using the Blower



Shut off the tractor engine and remove the key.



Wait for all components to stop rotating.

Do not place hands in the drive clutch area while the driveline is turning. Contact with the rotating drive line or pulley can cause serious injury.



Ensure all shields are in place and in good condition.

1. Close the lower auger housing cover.
 - Move the handle (1) to the closed position.




Do Not Contact the Rotating Auger.

Keep fingers and hands out of the auger chamber.

Never attempt to manually remove debris while the auger is rotating. Contact with the rotating auger will cause serious injury or death.

2. Close the upper auger housing cover.
 - Move the handle (2) to the closed position.
 - Place the pin firmly into the slot.



Close the Auger Housing Covers

221397C

3. Close and lock the auger transition housing door.




Do Not Contact the Rotating Blower.

Never attempt to manually remove debris while the blower is rotating. Contact with the rotating blower parts will cause serious injury or death.




- Remove the pin from the bottom of the cover (3).
- Remove the spring pin (4) from the hinge pin (5).
- Remove the hinge pin.



Close the Transition Housing Cover

212129C

- Rotate the cover to the closed position.
- Install the hinge pin (5).
- Install the spring pin (4).
- Install the bottom pin (3).



Lower the Transition Housing Access Cover

201033

4. Set the aggression level of the flails.

Adjust the aggression level of the flails with the guard rod adjustment crank handle (1).

To Increase the discharge rate:


- Turn the crank handle (1) to move the pointer (2) to a higher number on the decal.

To Decrease the discharge rate:

- Turn the crank handle (1) to move the pointer (2) to a lower number on the decal.

To avoid plugging, start by using an aggression setting of #2 or #3.

If the optional hydraulic aggression control is present, refer to "1 Remote Joystick Control For Bedding" for more information.



Set the Aggression Level of the Flails


222029C

5. Release the shield rubber latch on the blower drive shield.



Wait for all components to stop rotating.

Do not place hands in the TOP GUN drive clutch area while the driveline is turning. Contact with the rotating clutch or pulley can cause serious injury.



6. Raise the blower drive shield.

- Rest the shield in the tab on the back of the blower housing.




Lift the Blower Drive Shield


222142

7. Engage the blower drive clutch.

- Rotate the pulley to have the clutch pin near the top.



- Pull the handle (1) out and rotate into the hole (2) to engage the clutch pin into the sheave.
- The spring will pull the handle into the handle hole.
- The clutch pin will move into one of the sheave plate cutouts.
- If the clutch pin does not engage into a sheave cutout, manually rotate the sheave until the pin snaps into place.



Move Handle Into Engaged Position

221249C

8. Lower the blower drive shield and fasten with the rubber latch.

9. Lower the gearbox shield.

Controlling the TOP GUN For Bedding

Control Box - 3 Remote

The turret and nozzle are controlled by the electric console and hydraulic controls in the tractor cab.

To rotate the turret nozzle:

- On the control console, select Turret.
- Select Turret Swing.
- Operate the hydraulic lever which will engage the hydraulic motor to rotate the turret.



Lower Drive Shields


222143

To move the turret nozzle up/down:

- On the control console, select Turret.
- Select Turret Up/Down
- Operate the hydraulic lever to move the hydraulic cylinder which will raise or lower the turret nozzle.

To activate the Twine Sickle (if present):

- On the console select Twine Sickle.
- Operate the hydraulic lever which will engage the cylinder to move the sickle.



Control Box

41583_A

Bale Forks

The bale forks to load bales into the tub are controlled by the hydraulic remote in the tractor cab.

Feed Rollers

The direction of the bale feed rollers rotation is controlled by the hydraulic remote in cab.

1 Remote Joystick Control For Bedding

The thumb operated joystick has multifunction ability. These functions are shown on the decal.

Nozzle Height

The joystick controls the angle of the discharge nozzle. The nozzle can be raised or lowered. Refer to the decal on the joystick for the desired height movement.

Nozzle Rotate

The joystick controls the rotation of the discharge nozzle. Refer to the decal on the joystick for the desired rotation.

Bale Forks

The joystick controls the bale forks for loading bales into the tub. Use the joystick with the trigger depressed to raise or lower the bale forks.

Feed Rollers

The joystick controls the direction of rotation of the bale feed rollers. Move the rocker switch to rotate the rollers.

Twine Sickle (if present)

The twine sickle is controlled using the "Accessory" function on the joystick.


Optional Nozzle End Deflector (if present)

The nozzle end deflector is controlled using the "Accessory" function on the joystick.

- See "Using the Optional Nozzle End Deflector" in this section for more information.

Optional Aggression Control (if present)

The aggression level is controlled using the "Accessory" function on the joystick.



Joystick Control

Joystick Decal

Using the Optional Nozzle End Deflector

4 Remote Configuration

The optional nozzle end deflector cylinder is to be attached to a separate hydraulic lever.

Use the hydraulic lever to operate the cylinder which will raise or lower the end deflector.

- Raising or lowering the deflector will direct the material while the turret is being rotated and raised or lowered.




Optional Nozzle End Deflector
(Shown with the Optional Curved Chute)

220146

1 Remote Configuration (Joystick)

When the optional nozzle end deflector is installed with the 1 remote configuration (joystick) the joystick will control the operation of the end deflector cylinder.

- Use the joystick "Accessory" function with the trigger depressed to raise or lower the end deflector.



Joystick Accessory Function to Raise/Lower the End Deflector
Joystick Decal

Section 4 - Operating the BP 663


10. Rotate the nozzle to discharge the material to the desired area.
 - Rotate using the hydraulic motor.



Position the Turret Nozzle for Discharge

222190

- The range of nozzle movement is shown in the diagram.
11. Raise or lower the discharge nozzle for the desired amount of height and throw.
 - Use the hydraulic cylinder to raise or lower the nozzle.
 12. Engage the driveline to start the blower, processor and auger.
 13. Set the speed of the feed rollers.
 14. Begin to process a bale.
 - The belt-driven auger will move the material into the blower.



Range of Nozzle Movement

216101



Avoid discharging material in the area of people and animals.



Should any serious vibration be detected during the operation of the machine, immediately stop the machine. Determine the source of the problem and fix it before resuming operation.



Section 4 - Operating the BP 663

- Slowly start rotating the bale with the feed rollers.
- Bring the feed rollers up to a speed where the material is being fully processed.



Material or objects leaving the discharge area can cause serious injury or death. Do not operate within 100 ft (30m) of any person.

Note: If the feed rollers are rotating to fast they may dig into the bale. This may cause grooves which may result in the bale not being able to be turned.

Note: If the processor vibrates excessively, immediately disengage PTO and stop the tractor.




Wait for all flail drum rotation to stop before approaching the processor.

Inspect for blockages, missing flails or other causes of the vibration.



Begin Processing the Bale

221250



Section 4 - Operating the BP 663

15. Adjust the direction of bale rotation.

- Rotate the bale with the feed rollers so that the top of the bale moves toward the discharge side of the processor.
- If material begins to bunch up near the top of the bale, reverse the direction of bale rotation.
- If the bale stops rotating, reverse the direction of the feed rollers.




Adjust Direction of Bale Rotation

222080

16. Re-adjust the discharge rate if needed.

- If a different rate of material discharge is desired:
 - Stop the tractor and remove the key.
 - Wait until all flail drum rotation has stopped.
- Crank the guard rod adjustment handle (1) to move the guard rods as indicated on the rate lever pointer (2).
- Higher Number on the decal = more material discharged.
- Lower Number on the decal = less material discharged.



Re-Adjust Discharge Rate

222029C

17. Stop the feed rollers before loading another bale into the processor.




Shut Down Flail Drum When Loading Tub

221246

Operating For Feeding - Not Using the Blower (Feeding with the Auger)




Shut off the tractor engine and remove the key.



Wait for all components to stop rotating.

Do not place hands in the TOP GUN drive clutch area while the driveline is turning. Contact with the rotating drive line or pulley can cause serious injury.



Ensure all shields are in place and in good condition.



When feeding with the auger it is recommended to install the rubber paddles on the auger.

Note: If livestock is being fed, it is the operator's responsibility to ensure that the materials in the processed feed mix are suitable. Some of the wrapping material (twine, net wrap or other materials) may be discharged with the feed if the wrapping materials are not removed prior to processing.

1. Open the upper and lower auger housing doors to allow material to be discharged from the auger.



Do Not Contact Rotating Auger.

Keep fingers and hands out of the auger chamber.

Never attempt to manually remove debris while the auger is rotating. Contact with the rotating auger will cause serious injury or death. Keep all auger guards in place.


- Raise the upper auger housing door.
 - Lock the upper housing by placing the slot in the handle (1) over the pin.
- Lower the bottom auger housing door by moving the handle (2).



Open the Auger Housing Doors

221251C

2. Raise the transition housing cover.
 - Remove the pin from the bottom of the cover (3).
 - Place the pin back into the tabs.
 - Remove the spring pin (4) from the hinge pin (5) at the top of the cover.
 - Remove the hinge pin.
 - Rotate the cover to the open position.
 - Install the hinge pin (5).
 - Install the spring pin (4).



Raise the Transition Housing Cover

212129C

3. Set the aggression level of the flails.

Adjusting the aggression level of the flails is done by adjusting the guard rods with the adjustment crank handle (1).

To Increase the discharge rate:


- Turn the crank handle (1) to move the pointer (2) to a higher number on the decal.

To Decrease the discharge rate:

- Turn the crank handle (1) to move the pointer (2) to a lower number on the decal.

To avoid plugging, it is suggested to start with using an aggression setting of #2 or #3.

If the optional hydraulic aggression control is present, refer to "1 Remote Joystick Control For Feeding - Not Using the Blower" for more information.



Set the Aggression Level of the Flails


222029C

4. Release the shield rubber latch on the drive shield



Wait for all components to stop rotating.

Do not place hands in the TOP GUN drive clutch area while the driveline is turning. Contact with the rotating clutch or pulley can cause serious injury.



Section 4 - Operating the BP 663



5. Raise the blower drive shield.
 - Rest the shield in the tab on the back of the blower housing.
6. Raise the gearbox shield.



Lift the Drive Shield and Gearbox Shield

222142

7. Disengage the blower drive clutch.
 - Rotate the pulley to have the clutch pin near the top.
 - Pull the handle (1) out and rotate into the washer (2) to disengage the clutch pin from the sheave.
 - The spring will pull the handle into the washer.
 - The clutch pin (3) will move out of the sheave plate cutouts.



Move Handle Into Disengaged Position

221252C

8. Lower the blower drive shield and fasten with the rubber latch.
9. Lower the gearbox shield.



Lower the Drive Shields

222143


Controlling the TOP GUN For Feeding - Not Using the Blower (Feeding with the Auger)

Control Box - 3 Remote

Feeding is done with the auger.
The turret is not used for feeding when the auger doors are open.

To activate the Twine Sickle (if present):

- On the console select Twine Sickle.
- Operate the hydraulic lever which will engage the cylinder to move the sickle.



Control Box

41583_A

1 Remote Joystick Control For Feeding - Not Using the Blower (Feeding with the Auger)

The thumb operated joystick has multifunction ability. These functions are shown on the decal.

Nozzle Height

The nozzle is not used for feeding when the auger doors are open.

Nozzle Rotate

The nozzle is not used for feeding when the auger doors are open.

Bale Forks

The joystick controls the bale forks for loading bales into the tub. Use the joystick with the trigger depressed to raise or lower the bale forks.

Feed Rollers

The joystick controls the direction of rotation of the bale feed rollers. Depress the rocker switch to rotate the rollers.

Twine Sickle (if present)

The twine sickle is controlled using the "Accessory" function on the joystick.


Optional Nozzle End Deflector (if present)

The nozzle end deflector is not used for feeding.

Optional Aggression Control (if present)

The aggression level is controlled using the "Accessory" function on the joystick.

Note: Only one accessory can be controlled with the joystick.



Joystick Control

Joystick Decal

10. Engage the driveline to start the processor and auger.
11. Set the speed of the feed rollers.
12. Begin to process the bale.

Note: If livestock is being fed, it is the operator's responsibility to ensure that the materials in the processed feed mix are suitable. Some of the wrapping material (twine, net wrap or other materials) may be discharged with the feed if the wrapping materials are not removed prior to processing.

The auger is driven by the belt drive from the rear of the flail drum. The auger will discharge material out the side of the machine.



Should any vibration be detected during the operation of the machine, immediately stop the machine. Determine the source of the problem and fix it before resuming operation.



13. Drive ahead while operating the BP 663.




Avoid discharging material in the area of people and animals.



Section 4 - Operating the BP 663

14. Crossing ditches and steep inclines.


- Cross ditches or inclines at about a 30° approach angle.



Cross Ditch at 30° Angle

107072

- Do not approach a ditch or steep incline straight on as this may collapse the driveline to its shortest length, causing damage by pushing the PTO into the tractor or into the drivebox or downward onto the PTO shaft, breaking it off.




Driveline Collapsed in Steep Ditch

201221

15. Making turns.

- Do not make turns sharper than 80°.
- Angles greater than 80° can result in damage to the constant velocity joint and other driveline components.
- Ensure that the tractor tire does not contact the BP 663 deck or tongue.



Turn Less Than 80°

109040

Unplugging the BP 663 TOP GUN

1. Reduce the engine speed to idle.
2. Disengage the tractor power take off (PTO).
3. Set the tractor park brake and turn off the engine.



Shut off the tractor engine and remove the key.



Wait for all components to stop rotating.



Do Not Contact Rotating Auger. Keep fingers and hands out of the auger chamber.

Never attempt to manually remove debris while the auger is rotating. Contact with the rotating auger will cause serious injury or death.



Do Not Contact Rotating Blower. Keep fingers and hands out of the blower chamber when blower is rotating.

Never attempt to manually remove debris while the blower is turning. Contact with the rotating blower blades will cause serious injury or death.



Section 4 - Operating the BP 663

4. Release the shield rubber latch on the drive shield.

5. Raise the blower drive shield.

- Rest the shield in the tab on the back of the blower housing.

6. Raise the gearbox shield.



7. Disengage the blower drive clutch.

- Rotate the pulley to have the clutch pin near the top.
- Pull the handle (1) out and rotate into the washer (2) to disengage the clutch pin from the sheave.
- The spring will pull the handle into the washer.
- The clutch pin (3) will move out of the sheave plate cutouts.



Raise the Blower Drive Shield

222032



Move Handle Into Disengaged Position

221252C

8. Open the upper and lower auger housing doors.



Do Not Contact the Rotating Auger.

Keep fingers and hands out of the auger chamber.

Never attempt to manually remove debris while the auger is rotating.

Contact with the rotating auger will cause serious injury or death.

Keep all auger guards in place.

- Raise the upper auger housing door.
 - Lock the upper housing by placing the slot in the handle (1) over the pin.
- Lower the bottom auger housing door by moving the handle (2).




Open the Auger Housing Doors

221251C

9. Raise the transition housing cover.

- Remove the pin from the bottom of the cover (3).
 - Place the pin back into the tabs.
- Remove the spring pin (4) from the hinge pin (5) at the top of the cover.
- Remove the hinge pin.
- Rotate the cover to the open position.
- Install the hinge pin (5).
- Install the spring pin (4).



Raise the Transition Housing Cover

212129C

10. Clear the auger area.



Clear the Auger Area

221251

11. Clear the blower blade area.



Do Not Contact Rotating Blower. Keep fingers and hands out of the blower chamber when blower is rotating.

Never attempt to manually remove debris while the blower is turning. Contact with the rotating blower blades will cause serious injury or death.



Clear the Blower Area

222123

12. Open the access panel on the blower housing.

- Remove any material inside the housing.

13. Clear the nozzle of any material.

14. Replace the access panel and fasten in place.



Open Access Panel
Clear Blower Housing

222114

This Page Left Blank

MAINTAINING THE BP 663



Shut down the tractor and remove the key before repairing, servicing, lubricating or cleaning the machine.


Relieve all hydraulic pressure in the hoses. Disconnect the hydraulic hoses from the tractor before going near the machine.

Lubrication

Lubricate all grease fittings with a quality lithium soap compatible E.P. grease meeting the N.L.G.I. #2 specifications and containing no more than 1% molybdenum disulfide.

Every 8 Hours

- PTO - Lubricate 5 points on the PTO every 8 hours.
 - 1 point each constant velocity joint.
 - *Continued angled operation will require lubrication every 4 hours.
 - 1 point on each joint collar
 - 1 point at the telescoping section




Grease Points on PTO

221219C

Every 16 Hours

- Lubricate 3 points on the driveline joint connecting the clutch to the flail drum gearbox.




Grease Clutch Driveline Joint

221402C

Section 5 - Maintaining the BP 663

- Lubricate 1 point on the auger at the rear of the machine.




Grease Auger Bearing

216223C

Every 50 Hours

- Lubricate 1 point on the rear flail drum bearing at the back of the machine.



Grease Rear Flail Drum Bearing

201223C

- Lubricate 2 points on the over running clutch located on the driveline going to the front of the blower.



Grease the Over Running Clutch

222192C

Section 5 - Maintaining the BP 663


- Lubricate 2 points on the blower clutch shaft.
 - Raise the clutch drive shield.
 - Lubricate the rear bearing.
 - Lubricate the front bearing.



Grease Blower Clutch Shaft
(Panel Shown Removed)

221403C

- Lubricate the blower impeller bearings.
 - Use the 2 remote grease points located near the blower cover opening.



Grease Impeller Bearings
Remote Grease Points

222113C

- Lubricate the rear flail drum bearing.
 - Open the auger drive shield on the rear tub wall.
 - The bearing grease zerk is behind the sheave on the flail drum shaft.




Grease Rear Flail Drum Bearing

221401C

Every 100 Hours

- Lubricate 1 point at the front for each feed roller.



Grease Front Feed Roller Bearings

222144C

- Lubricate 1 point at the rear for each feed roller.



Grease Rear Feed Roller Bearings

221396C2

- Hubs on spindles - Lubricate both hubs every 100 hours.



Grease the Hub on Both Spindles

221151C

- Grease the twine sickle every 100 hours.
 - Grease one point on the top of the sickle.




Grease the Twine Sickle

221243C

Every Season

- Lubricate the turret chain (2) once every season.
 - Use a quality chain oil.
- When storing for the season:
 - Oil the turret chain with a rust inhibiting oil or coating to prevent weathering.



Lubricate the Turret Chain

222036C

Visually Inspect Hydraulic Hoses/Fittings

Shut down the machine and disconnect the hoses from the tractor. Relieve pressure from the hoses.

Replace the hydraulic hose assembly if any of the following conditions exist:

- Fitting slippage on hose.
- Damaged, cracked, cut or abraded cover (any reinforcement exposed).
- Hard, stiff, heat cracked or charred hose.
- Cracked, damaged or badly corroded fittings.
- Leaks at fitting or in hose.
- Kinked, crushed, flattened or twisted hose.
- Blistered, soft, degraded or loose cover.




Inspect Hydraulic Hoses
(3 Remote Shown)

108008-1

Check the Fluid Level in the Flail Gearbox

- Check the oil fluid level by removing the oil level plug (1) in the center of the gearbox.
- The oil should be at the level of the plug.
- If oil needs to be added, add through the breather (2) on the top of the gearbox.
- Use gear oil Grade 80W90 that meets or exceeds API service classification GL-4.
- Annually change the oil in the gearbox. (See Gearbox Oil Changing Procedures)



Check Gearbox Oil Level
(Driveline Shown Removed for Clarity)

222193C

Flail Gearbox Oil Changing Procedure

Change the oil annually and before storing the BP 663 for the season.




Before beginning, make sure the tractor is off and the PTO is disengaged. Disconnect the driveline from the tractor before doing any work.



Securely block the BP 663 before any work is done to prevent the BP 663 from moving during servicing.


1. Drain the oil from the gearbox.
 - Remove the drain plug (1) on the bottom of the gearbox.
 - Allow the oil to drain completely from the gearbox.
 - Catch the oil in a container.



Changing the Gearbox Oil
(Driveline Shown Removed for Clarity)

222193C2

2. Replace the drain plug (1) and tighten.
3. Fill the Gearbox.
 - Remove the top breather plug (2).
 - Fill with 300 ml of 80W90 gear oil that meets or exceeds API service classification GL-4.
4. Check the oil level in the gearbox.
 - Removing the oil level plug (3) in the center of the gearbox.
 - The oil should be at the level of the plug.
 - If oil needs to be added, add through the breather plug (2) on the top of the gearbox.



Changing the Gearbox Oil
(Driveline Shown Removed for Clarity)

222193C2

Flail Replacement Procedure

Replace flails that are broken or worn to the point that they will not process material properly.



Before beginning, make sure the tractor is off and the PTO is disengaged. Disconnect the driveline from the tractor before doing any work.




Securely block the BP 663 before any work is done to prevent the BP 663 from moving during servicing.

1. Remove the flail to be replaced.
 - Remove the nut (4) and bolt (5) that holds the flail (3) to the drum (1).
2. Remove the pipe (2) inside the flail.
 - This pipe will be used again.



TORQUE CARRIAGE BOLTS TO A MIN.
OF 180 FT-LBS (MAX. 240 FT-LBS).




Flail Replacement

40524_B

3. Remove the flail that is on the opposite side of the flail drum.

Note: To maintain rotary balance, the flail on the opposite side of the drum must be replaced at the same time.


4. Install the 2 new flails with the pipe, bolt and nut between the tabs on the drum.
 - Ensure that the bent portion of the flail leads into the rotation of the drum.
5. Torque the nuts to minimum of 180 ft-lb (244 Nm) - maximum of 240 ft-lb (325 Nm).
6. Check that the flail freely moves between the tabs on the drum.



Replacing the Blower Blades

Replace all the blower blades if:

- Any blade is cracked (1) at the bend.
- Any blade thickness is 1/8" (3.2mm) or less.
- Replace all the blades as a set to maintain rotational balance of the blower.
- Use only genuine Highline parts.



Replace Worn or Cracked Blades

216062-1C

To Replace the Blades:

1. Fasten a lifting strap in the lifting tab (1) on the front plate of the blower.
 - Tighten the lifting strap with a lifting device to take the weight of the front plate.
2. Remove all the nuts and bolts (2) from the blower housing front plate.
 - Keep these fasteners as they will be used when replacing the front plate.




Remove the Blower Front Plate

222182C

3. Remove the front plate with the lifting device.

Note: It is not necessary to remove the blower impeller to replace the blades.




Remove the Front Blower Plate

221263

4. Open the blower access panel by removing the top nut (1) and the 2 side nuts.

- Lower the panel.




Open the Blower Access Panel

221264C

Section 5 - Maintaining the BP 663

5. Reach through the access opening to place a wrench onto the nuts (2) holding the blade.
6. From the blower backing plate, remove the bolts from the blade.
 - Keep fasteners for re-use.
7. Fasten the new blade onto the backing plate with the bolts and nuts (2).
 - Use only Highline replacement parts.
 - Torque the bolts to 170 lbft (230 Nm)
8. Rotate the blower by hand and replace all the blades to maintain rotational balance.
9. Lift the blower front plate back into place.
 - Fasten the plate with the bolts and nuts.
 - Torque the bolts to 35 lbft (47 Nm).



Remove Bolts/Nuts to Replace the Blade

222114C



Replace the Front Blower Plate

222182

Replacing the Blower Wear Plate

The blower housing wear plate is located inside the blower on the discharge side.


The amount of wear plate will depend on the amount of bales processed and the type of bales.

- Abrasive bales such as corn bales cause the plate to wear out more quickly.

See Section 3 - "BP 663 Preparation" for instructions on how to check the condition of the blower housing wear plate.

The typical high wear area occurs just below the blower housing access panel. (See the diagram.)

- When the wear plate is worn through at the location shown (or any other area), replace or reverse the plate to avoid wearing out the blower housing structure.



Check Blower Wear Plate
(Impeller Shown Removed for Clarity)

222034-1C

To Replace or Reverse the Wear Plate:

1. Fasten a lifting strap in the lifting tab (1) on the front plate of the blower.
 - Tighten the lifting strap with a lifting device to take the weight of the front plate.
2. Remove all the fasteners (2) from the blower housing front plate.
 - Keep these fasteners as they will be used when replacing the front plate.




Remove the Blower Front Plate

222182C

Section 5 - Maintaining the BP 663

3. Remove the front plate with the lifting device.

Note: The impeller does not need to be removed to change/reverse the wear plate.



Remove the Front Blower Plate


221263

4. Remove 12 of 3/8" x 1-1/4" plow bolts (2) and locknuts from the wear plate.

- Keep these fasteners to be used to install the new wear plate.

5. Remove the wear plate (3).

- Discard this plate if being replaced.
- Keep the plate if being reversed.



Remove, Reverse/ Replace Blower Wear Plate^{222115C}
(Impeller Shown Removed for Clarity)

6. Place the new wear plate (3) into the housing or reverse the existing wear plate in the blower housing.

7. Fasten with 12 of 3/8" x 1-1/4" plow bolts (2) and 3/8" flange locknuts into the wear plate and the blower housing.

8. Tighten all the wear plate fasteners to 35 lbft (47Nm).

9. Lift the blower front plate back into place.

- Fasten the plate with the bolts and nuts removed earlier.
- Torque to 35 lbft (47Nm).




Replace the Front Blower Plate

222182


Replace the Turret Elbow Wear Liner

- Place a lifting strap on the nozzle lifting loop (2) to take the weight of the nozzle (1).
- Remove all the fasteners (3) that hold the nozzle to the elbow.
 - Keep the fasteners for re-use.
- Remove the nozzle (1) from the elbow.
- Retract the elbow cylinder (7) to show the elbow liner (6).



Place a Lifting Strap on the Nozzle

222116C




Retract the Elbow Cylinder

222110C-1

Section 5 - Maintaining the BP 663

- Remove the liner fastening nuts (4) from back of the elbow.
- Keep the fasteners for re-use.



Remove the Elbow Liner Nuts

222117C

- Reach inside the elbow to remove the carriage bolts (5) that go through the elbow liner.

Note: Take care to not let the bolts fall down into the blower.


- Keep the fasteners for re-use.



Remove Bolts from Inside the Elbow.

222118C

- Pull out the old elbow liner (6) from the elbow.
- Insert the new liner (6) into the elbow.




Insert the New Liner into the Elbow

222110C-1

Section 5 - Maintaining the BP 663

- Place the liner (1) behind the tabs (8) at the top of the elbow.




Place the Elbow Liner Behind the Tabs

222119C

- Reach inside the elbow and insert the 3/8" x 1" carriage bolts (5) through the elbow liner and into the slots in the elbow.
- Use the fasteners removed earlier.


Note: Take care to not let the bolts fall down into the blower.



Insert the Bolts from Inside the Elbow.

222118C


- On the back of the elbow, fasten the liner with 3/8" locknuts (4) on the carriage bolts.
- Torque to 35 lbft (47 Nm).



Fasten the Elbow Liner with Nuts

222117C

- Replace the nozzle (1) onto the elbow by lifting it with a strap attached to the lifting loop (2).
- Attach with the 1/2" x 1-3/4" carriage bolts and flange locknuts (3) that were removed earlier.
- Torque to 85 lbft (115 Nm).



Replace the Nozzle onto the Elbow

222116C

Blower Belt Tension Adjustment

The blower belt tension adjuster has a spring to keep the tension.


- The belt is tensioned from the factory.

To confirm adequate belt tension:

- Check if the spring washer (1) is showing in the cut out window (2).
 - If it is showing in the window then the belt tension is in the acceptable range.

To adjust belt tension:

- If the spring washer (1) is not showing in the cut out window (2) then adjust the belt tension by:
 - Loosening the jam nut (3) on the threaded rod.
 - Turn the nut (4) next to the spring washer to adjust the spring so it shows in the cut out window (2).
 - Tighten the jam nut (3).



Blower Belt Tension Adjustment

219061C

Auger Belt Tension Adjustment

The auger belt tension adjuster has a spring to keep the tension.

- The belt is tensioned from the factory.

To confirm adequate belt tension:

- Check if the spring washer (1) is showing in the cut out window (2).
 - If it is showing in the window then the belt tension is in the acceptable range.

To adjust belt tension:


- If the spring washer (1) is not showing in the cut out window (2) then adjust the belt tension by:
 - Loosening the jam nut (3) on the threaded rod.
 - Turn the nut (4) next to the spring washer to adjust the spring so it shows in the cut out window (2).
 - Tighten the jam nut (3).

Replacing/Installing the Optional Rubber Auger Paddles

The optional rubber auger paddles are manufactured to a tight weight tolerance to maintain rotational balance of the auger. Replace only with Highline replacement parts.

If a paddle is damaged, replace all 5 paddles as a set to maintain the rotational balance of the auger.

- Remove the ballast plates.
 - Discard the ballast.
 - Keep the fasteners for re-use.
- Install the rubber paddles (2) with the bolts (4), flatwashers (3) and locknuts (5) that were removed.




Auger Belt Tension Adjustment

221230C



Replace All Auger Paddles As A Set

213082



Install the Optional Rubber Paddles


222120

Adjusting the Hydraulic Motor Gear Into the Turret Chain

The gear on the turret motor should be fully engaged into the chain on the turret.


To adjust the gear engagement:

- Remove the fasteners (1) from the gear cover.
- Remove the gear cover.
- Loosen the motor mount bolts (2) to allow the motor mount plate to slide.
- Loosen the engagement adjustment jamnut (3).
- Turn the adjustment bolt (4) to move the motor plate along the slots until the gear is fully engaged into the chain.
- Tighten the motor mount bolts (2).
- Tighten the adjustment jamnut (3).
- Replace the gear cover and fasten in place.



Remove The Gear Cover

222037C



Adjust Gear Engagement

213012C

Tires


Note: It is recommended to have the tires mounted by a tire technician.

- Check the condition of the tires.
- Mount the rim so that the air valve will be facing outward when mounted on the BP 663.
- Place the cone side of the lug nut against the wheel rim. Torque to 75 lb-ft (101 Nm).
- Tire Pressure - Fill the tires to 24 psi (165 Kpa).
- When replacing the tires, refer to the Specification Section for the size and type of tires.
- Transport speed for should not exceed 25 mph (40 kmh).



Tires

221128




Tire Mounting

107094CC

Axles

- Check that the axle u-bolts are tight.
- Torque the axle u-bolts (1) to 200 lb-ft (270 Nm) to ensure the axles do not slide out of the frame.
- Maximum axle extension is 14" (355 mm) from the main tube edge to the inside face of the spindle plate.



Check That Axle U-bolts Are Tight

221129C

- Remove any twine that is built up around the axle spindle and hub.
- Be careful to not damage the grease seal on the bearing while removing twine.



Remove Twine From the Spindle and Hub

221130

This Page Left Blank

STORING THE BP 663

1. Clean all the debris from the tub area and off the BP 663.
2. Park the BP 663 on level ground.
3. Lubricate all BP 663 grease points (See Section 5).
4. Tighten all the bolts to the recommended torque.
5. Check the BP 663 for worn and damaged parts. Replace as needed.
6. Lock the BP 663 flail drum.
 - Turn the lock pin to release the roll pin from the slot.
 - Allow the spring to push the lock pin into the processing chamber.
 - Manually rotate the driveline until the lock pin snaps into place locking the flail drum.



Clean Debris from the BP 663

222190



Lock the Flail Drum

221364

Section 6 - Storing the BP663

7. Lower the forks to the ground.

- Fasten the fork lock in the storage position.
- Retract the extendable forks.




Lower Forks to the Ground
(Extendable Forks Shown)

221232

8. Place the jack onto the hitch.

- Remove the jack from the storage position.
- Pin the jack in place on the hitch.
- Release the drop foot and raise the hitch until the weight is supported by the jack.
 - The jack has a 2 speed operating crank. (Refer to image on the top of the jack).
- Ensure that the jack is resting on solid level ground or resting on a wood block.



Jack on Hitch - Raise Hitch

221221-2

9. Remove the driveline from the tractor PTO shaft.

- Support it in the PTO holder.
- Disconnect the chain on the driveline guard from the tractor.

10. Disconnect the safety chain from the tractor.

11. Disconnect the hitch from the tractor.

- Remove the hitch pin.



Remove Driveline and Safety Chain

221220

Section 6 - Storing the BP663

12. Relieve the pressure on the hydraulic hoses and disconnect them.

13. Disconnect the electrical connection.



Disconnect Hydraulic Hoses & Electrical
(3 Remote Shown)

108008

14. Secure the hydraulic hoses and electrical connector to the hose holder to keep them off the ground and clean.



Hoses and Driveline in Supports

222192

15. Change the oil in the gearbox. See the Maintenance Section for procedures.
 - Fill the gearbox to the oil level as outlined in the Maintenance Section.
16. Check the BP 663 for worn and damaged parts. Replace as needed.
17. Touch-up the paint to prevent rusting.

This Page Left Blank

7.0 TROUBLESHOOTING

Symptom	Problem	Solution
Bale lifting problems	Forks do not raise	Check hydraulic connections and lines.
	Electric solenoid valve (if present)	Check the electrical connection to the solenoid.
		Check that hydraulic fluid passes through the solenoid valve.
	Not responding to joystick (if present)	Check cable and connector.
		Measure voltage at the connector.
		Refer to manifold layout.
		Manually push/pull the rod of the valve. Avoid being harmed by sudden movements of the machine. Replace solenoid.
	Bale tips off back of forks	Narrow forks for a better lift on bale.
		Extend the forks.
	Bale hung up on forks - not going into the tub	Cycle feed rollers left to right to pull bale into tub.
Material builds up on one side of bale in tub	Bale unwrapping in tub	Reverse direction of feed rollers to consume material buildup.
Difficult to rotate bale in tub	Feed rollers not fully engaging bale	Increase aggression of flails to help rotate bale.
		Roll bale into the direction of the auger.
	Bale on forks contacting bale in tub	Lower the bale on the forks.
	Twine buildup on rollers	Remove twine from rollers.

Section 7 - Troubleshooting

Symptom	Problem	Solution
Bale Not Rotating	Feed rollers not engaged	Slowly engage the feed rollers to get the bale rotating.
Feed rollers not turning	SCV not supplying enough hydraulic flow	Increase the flow rate at the SCV.
	Not responding to joystick (if present)	Check cable and connector.
		Measure voltage at the connector.
		Refer to manifold layout.
		Manually push/pull the rod of the valve. Avoid being harmed by sudden movements of the machine. Replace solenoid.
PTO and flail drum not turning	Flail drum lock engaged	Disengage drum lock.
	Driveline shear bolt	Replace shear bolt on drive line.

Blower

Symptom	Problem	Solution
Excessive Blower Vibration	Broken blade	Replace all the blades of the blower to maintain rotational balance.
	Missing blade	Replace all the blades of the blower to maintain rotational balance.
	Foreign material lodged in blower	Remove foreign material.
		Check for damage to the rotor. Contact Highline for proper repair procedure.

Section 7 - Troubleshooting

Symptom	Problem	Solution
	Failed bearing	Check if rotation feels rough. Replace bearing.
		Check for bearing side play and end play. Replace failed bearing.
		Visually inspect bearing. Replace failed bearing.
		Check condition of the grease seal.

Blower Does Not Spin	Drive clutch is not engaged	Twist the clutch engage handle to move to the Engaged Position. Rotate the sheave until the drive pin snaps into a connecting hole in the drive plate. Ensure the drive pin is fully forward into the drive plate.
	Broken belt	Replace the belt.
	Foreign material lodged in housing	Remove foreign material to allow blower to spin freely. Check condition of blades. Replace all the blades of the blower to maintain rotational balance.
	Blower bearing has seized	Check bearings or replace.

Blower Stops Spinning	Blower drive clutch pin has moved out and no longer is engaged with the drive plate	Twist the clutch engage handle to move to the Engaged Position. Rotate the sheave until the drive pin snaps into a connecting hole in the drive plate. Ensure the drive pin is fully forward into the drive plate.
	Belt has come off the sheaves or tensioner	Place the belt on the sheaves and the tensioner. Check the alignment of the sheaves and tensioner. Adjust if needed.

Section 7 - Troubleshooting

	Broken belt	Replace the belt.
	Belt tension	See Section 5 "Blower Belt Tension Adjustment" for instructions on adjusting belt tension.

Drive Belt Loose	Belt tension	See Section 5 "Blower Belt Tension Adjustment" for instructions on adjusting belt tension.
	Belt has stretched	Replace the belt.
		See Section 5 "Blower Belt Tension Adjustment" for instructions on adjusting belt tension.

Blower Turret

Symptom	Problem	Solution
Blower Turret Does Not Turn	Turret chain has come loose or is broken	Tighten chain. Replace chain.
	Hydraulic motor sprocket not engaged in chain	Adjust the hydraulic motor position so the gear is fully engaged into the chain. Tighten the motor mount.
	Foreign material lodged in rotational plates	Remove foreign material to allow turret to move freely.
	Diverter valve	Confirm operation of the hydraulic diverter valve.
		Check that there is 12 volts at the solenoid connection when the turret swing switch is activated.
		Check that the solenoid is working - "clicks" when activated.

Section 7 - Troubleshooting

Symptom	Problem	Solution
	Hydraulic motor	Check hydraulic connections.
		Replace hydraulic motor.
	Not responding to joystick (if present)	Check cable and connector
		Measure voltage at the connector.
		Refer to manifold layout
		Manually push/pull the rod of the valve. Avoid being harmed by sudden movements of the machine. Replace solenoid.

Nozzle does not lift or lower	Hydraulic cylinder	Check hydraulic connections.
	Cylinder pin missing	Replace cylinder pin.
	Material lodged in joint	Remove material.
	Not responding to joystick (if present)	Check cable and connector
		Measure voltage at the connector.
		Refer to manifold layout .
		Manually push/pull the rod of the valve. Avoid being harmed by sudden movements of the machine. Replace solenoid.

Auger

Symptom	Problem	Solution
Excessive Auger Vibration	Broken flighting	Replace auger.
	Missing or damaged rubber paddle (if present)	Replace all the paddles as a set to maintain rotational balance.

Section 7 - Troubleshooting

Symptom	Problem	Solution
	Foreign material lodged in auger	Remove foreign material.
	Failed bearings	Check if rotation feels rough. Replace failed bearing.
		Check for side and end play. Replace failed bearing.
		Visually inspect bearings. Replace failed bearings.
	Bent auger tube	Replace auger.

Auger Does Not Spin	Broken belt	Replace the belt.
	Belt has stretched	Replace the belt.
		See Section 5 "Auger Belt Tension Adjustment" for instructions on adjusting belt tension.
	Foreign material lodged in auger chamber.	Remove foreign material to allow auger to spin freely. Check condition of flighting and paddles. Replace paddles.
	Auger bearing has seized	Check bearings or replace.

Auger Stops Spinning	Belt has come off the sheaves or tensioner	Place the belt on the sheaves and the tensioner. Check the alignment of the sheaves and tensioner. Adjust if needed.
	Broken belt	Replace the belt.

Drive Belt Loose	Belt tension	See Section 5 "Auger Belt Tension Adjustment" for instructions on adjusting belt tension.
	Belt has stretched	Replace the belt.

Section 7 - Troubleshooting

		See Section 5 "Auger Belt Tension Adjustment" for instructions on adjusting belt tension.
--	--	---



Hydraulic Manifold - Joystick Option

Symptom	Problem	Solution
Solenoid valve	Electrical fault	Check cable and connector.
		Measure voltage at the connector.
	Not responding to joystick	Manually push/pull the rod of the valve. Avoid being harmed by sudden movements of the machine. Replace solenoid.
		Refer to manifold layout.

End Deflector Option, Twine Sickle Option, Hydraulic Aggression Option

Symptom	Problem	Solution
Solenoid valve	Hydraulic	Check the hydraulic connection to the cylinder.
	Electrical fault (Joystick)	Check cable and connector.
		Measure voltage at the connector.
	Not responding to joystick	Manually push/pull the rod of the valve. Avoid being harmed by sudden movements of the machine. Replace solenoid.
		Refer to manifold layout.

Joystick Hydraulic Manifold Layout



Section 8 - Specifications

BP663 TOP GUN® SPECIFICATIONS

Width

Transport Width	108 ½" (2756 mm)
-----------------	------------------

Height

Transport Height (Nozzle)	131 ½" (3340 mm)
Transport Height	
Standard Forks	131 ¼" (3330 mm)
Extendable Forks (Raised and Retracted)	139 ½" (3543 mm)
Working Height Maximum	
Standard Forks	154 ½" (3920 mm)
Extendable Forks (Forks Extended)	190" (4826 mm)
Extendable Forks (Forks Retracted)	164 ½" (4178 mm)

Length

Length To End of Tires	
Standard Forks	203 ½" (5169 mm)
Extendable Forks	203 ½" (5169 mm)
Length To End of Forks Down	
Standard Forks	266 ¼" (6763 mm)
Extendable Forks (Forks Extended)	306" (7772 mm)
Extendable Forks (Retracted)	279" (7087 mm)

Weight

Machine Weight	
Standard Forks	7778 lb (3528 kg)
Tongue weight (Unloaded)	2715 lb (1232 kg)
Extendable Forks	8485 lb (3849 kg)
Tongue weight (Unloaded)	2815 lb (1277 kg)

Section 8 - Specifications

PTO

Recommended PTO	165 HP (124 kW)
	1000 PTO -1 3/8" 21 spline with over-running clutch
	Cat.8/1000 rpm
Constant Velocity Turning Range	Maximum 80 degrees

Gearbox rating	180 hp rating (134 kilowatt)
Gearbox Oil Capacity	300 ml

Bale Size

Maximum Size of Round Bale	6 feet (1.8 m) diameter
Maximum Size of Square Bale	4' x 4' x 8' (1.2 x 1.2 x 2.4 m)

Tires	16.5LX 16.1 ANS Inflate to 24 psi (165 kPa)
-------	--

Note: Right/Left hand is determined by sitting in the tractor looking forward.

Highline New Equipment Limited Warranty Policy

One (1) Year / 12 Months - Parts and Labour

Highline Mfg. (hereinafter "Highline") warrants this new product of Highline's manufacturer to be free from defects in material and workmanship, under normal use and service for one (1) full year after initial purchase/retail sale. Highline will warrant its product for one (1) year parts and labour, if performed by a qualified Dealer. This Limited Warranty shall apply only to complete machines of Highline's manufacture. Parts are covered by a separate Limited Warranty.

EQUIPMENT AND ACCESSORIES NOT OF HIGHLINE'S MANUFACTURE ARE WARRANTED ONLY TO THE EXTENT OF THE ORIGINAL MANUFACTURER'S WARRANTY AND SUBJECT TO THEIR ALLOWANCE TO HIGHLINE ONLY IF FOUND DEFECTIVE BY SUCH MANUFACTURER.

During the Limited Warranty period specified above, any defect in material or workmanship in any warranted item of Highline Equipment not excluded below shall be repaired or replaced at Highline's option without charge by any authorized independent Highline Dealer. An authorized Dealer must make the warranty repair or replacement. Labour in accordance with Highline's labour reimbursement policy. Highline reserves the right to supply remanufactured replacement parts as it deems appropriate.

RETAIL PURCHASER RESPONSIBILITY

This Limited Warranty requires proper maintenance and periodic inspections of the Equipment as indicated in the Operator's Manual furnished with each new Equipment. The cost of routine or required maintenance and services is the responsibility of the retail purchaser. The retail purchaser is required to keep documented evidence that these services were performed. This Highline New Equipment Limited Warranty may be subject to cancellation if the above requirements are not performed.

EXCLUSIONS AND LIMITATIONS

The warranties contained herein shall NOT APPLY TO:

1. Any defect which was caused (in Highline's sole judgement) by other than normal use and service of the Equipment, or by any of the following:
 - a. accident
 - b. misuse or negligence
 - c. overloading
 - d. of reasonable and proper maintenance
 - e. improper repair or installation
 - f. unsuitable storage
 - g. non-Highline approved alteration or modification
 - h. natural calamities
 - i. vandalism
 - j. parts or accessories installed on Equipment which were not manufactured or installed by Highline authorized Dealers
 - k. the elements
 - l. collision or other accident
2. Any Equipment whose identification numbers or marks have been altered or removed.
3. Any Equipment which any of the required or recommended periodic inspection or services have been performed using parts not manufactured or supplied by Highline or meeting Highline Specifications including, but without limitation, lubricants (oil, grease), belt lacings, and hydraulic fluids.
4. Any Equipment used in demonstrations not performed by a Highline Dealer. Warranty will be at the discretion of Highline for all other demonstration warranty.
5. New Equipment delivered to the retail purchaser in which the warranty registration has not been completed and returned to Highline within thirty (30) days from the date of purchase.
6. Any defect that was caused (in Highline's sole judgement) by operation of the Equipment not abiding by standard operating procedures outlined in the Operator's Manual.
7. Tire Limited Warranties and support are the responsibility of the respective product's manufacturer.
8. Transportation costs, if any, of transporting to the Highline Dealer.
9. In no event shall Highline's liability exceed the purchase price of the product.
10. Highline shall not be liable to any person under any circumstances for any incidental or consequential damages (including but not limited to, loss of profits, out of service time and damage to equipment which this equipment may be attached) occurring for any reason at any time.

11. Diagnostic and overtime labour premiums are not covered under this Limited Warranty Policy.
12. Depreciation damage caused by normal wear, lack of reasonable and proper maintenance, failure to follow operating instructions, misuse, and/or lack of proper protection during storage.
13. Accessory systems and electronics not of Highline's manufacture are warranted only to the extent of such manufacturer's respective Limited Warranty if any.
14. Wear items which are listed by product group below:

COMMON WEAR ITEMS

Roller chain, sprockets, clutches, shear bolts, clutch components, chains, gearbox housings bolts/torqued parts, flails, feed roller belting, coupler chain, DRV couplers, bogie wheels, apron tines and hoses, blades and blade pans, blade bolts and nuts, skid shoes, chain guards, clutches and clutch components.

PARTS WARRANTY

Parts replaced in the warranty period will receive the balance of the one year New Equipment Limited Warranty. Replacement parts after the original machine warranty are warranted to be free from defects of material for ninety (90) days or the part will be repaired or replaced, without labour coverage for removal and reinstallation.

EXCLUSION OF WARRANTIES

UNLESS OTHERWISE REQUIRED BY LAW, AND EXCEPT FOR THE WARRANTIES EXPRESSLY AND SPECIFICALLY MADE HEREIN, HIGHLINE MAKES NO OTHER WARRANTIES, AND ANY POSSIBLE LIABILITY OF HIGHLINE HEREIN UNDER IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTIES OF MERCHANT ABILITY OR FITNESS FOR A PARTICULAR PURPOSE. HIGHLINE RESERVES THE RIGHT TO MODIFY, ALTER AND IMPROVE ANY PRODUCT WITHOUT INCURRING ANY OBLIGATION TO REPLACE ANY PRODUCT PREVIOUSLY SOLD WITH SUCH MODIFICATION. NO PERSON IS AUTHORIZED TO GIVE ANY OTHER WARRANTY, OR TO ASSUME ANY ADDITIONAL OBLIGATION ON HIGHLINE'S BEHALF.